MR7622 Series USB HID Keyboard Simulator IC Card Reader

User's Manual

(Revision 4.01)

Jinmuyu Electronics Co. LTD May 7, 2015





Contents

1	Overview		2	
2	Main Characteristics			
3	Technical parameters			
4	Cards supported			
5	Model of the reader			
		odel format		
	5.2 Model description			
	5.2.1	Product code		
	5.2.2	Device class	4	
	5.2.3	Communication port	5	
	5.2.4	Supported card type		
	5.2.5	Color of enclosure	5	
	5.2.6	ODM code	5	
	5.3 Model available		5	
6	USB Driver	installation	5	
7	About PC So	oftware	6	



1 Overview

MR7622 series desktop contactless IC card reader is based on NXP series RF chip with high performance MCU. The communication is according to USB HID standard. There are 2 USB devices to implement the functions. One is USB keyboard for DATA output. The other is USB compliant device for DATA output format configuration and ISP function. The DATA output format is very flexible. The reader could output any sector any byte in any format. TransConfig, the configuration tool is very easy to use to load the



configuration file to reader. The configuration file is easy to build. Please to read "JINMUYU USB HID Keyboard Simulator IC Card Reader General Technical Manual.pdf" to build the configuration files. And we will help you to make the configuration file.

The reader supports the IC card according to ISO14443A, ISO14443B and ISO15693 standard.

2 Main Characteristics

- USB HID keyboard simulator data output
- Data output format is very flexible
- RF interface and protocol process with EMV2010 LEVEL 1 certification ability
- Delicate outer casing

3 Technical parameters

PCD: MF RC531, SL RC400, CL RC632

• Working frequency: 13.56MHz

RF protocol: ISO14443A, ISO14443B, ISO15693
Operating distance: 100mm (MIFARE One, typical)
Display: 4 LEDs, blue, yellow, green, red

• Buzzer: Build in

Interface: dual port, USB HID keyboard simulator and USB HID compliant device

• Power supply: $DC5V \pm 10\%$

• Power consumption: 0.9W

• Dimension: 135mm * 100mm * 45mm

Weight: About 100g
Operating temperature: -25 ~ +85°C
Storage temperature: -40 ~ +125°C



PC software: no need, direct output to editor

ISP: Support RoHS: Compliant

4 Cards supported

	MR7622UC	MR7622UG	MR7622UH
PCD	MF RC531	SL RC400	CL RC632
MIFARE 1K	•		•
MIFARE 4K	•		•
MIFARE Mini	•		•
MIFARE Ultra Light	•		•
MIFARE Ultra Light EV1	•		•
MIFARE Plus Level 1	•		•
T=CL TYPE A	•		•
T=CL TYPE B	•		•
I.CODE SLI		•	•
I.CODE SLI-S		•	•
TI Tag-it series		•	•
ST LRI series		•	•
Other ISO15693 tags		•	•



Model of the reader

5.1 Model format

This is the model format of Master Reader series contactless card reader/writer:

1	2	3	4	5	6
MR	XXX	X	X	X	-XXX

- 1: Product code; 2: Device class; 3: Communication port; 4: Supported card type;
- 5: Color of enclosure; 6: ODM code;

Model description 5.2

5.2.1 Product code

The code of Master Reader series contactless card reader is: MR

5.2.2 Device class

- 600: Desktop readers with 8 digits LED displayer, support 1 SAM slot.
- 701: Desktop readers, support 2 SAM slots.
- 730: Desktop readers, Ethernet interface, support 1 SAM slot.
- 731: Desktop readers, Ethernet interface, support 2 SAM slots. MR730 Enhanced with more advance.
- 762x: Desktop read only programmable reader. Keyboard simulator. Support ISO14443A/B, ISO15693.
- 763x: Desktop read only programmable reader. Keyboard simulator. Support ISO14443A, ISO14443B.
- 780: Desktop reader, MR701 enhanced model. Support 3 SAM slots.
- 7801: Desktop reader, MR780 in new style case. Support 4 SAM slots.
- 790: Desktop reader with compatible PC/SC interface. Support 3 SAM slots.
- 7901: Desktop reader with compatible PC/SC interface. MR790 in new style case. Support 4 SAM slots.
- 791: Desktop reader with standard PC/SC interface. Support 3 SAM slots.
- 7911: Desktop reader with standard PC/SC interface. MR791 in new style case. Support 4 SAM slots.
- 800: Desktop reader with 128*64 dots LCD displayer. Compatible PC/SC interface, support 2 SAM slots.
- 801: Desktop reader with 128*64 dots LCD displayer. Standard PC/SC interface, support 2 SAM slots.
- 810: Desktop reader with compatible PC/SC interface. Support 2 SAM slots. Based on ARM7 processor.
- 811: Desktop reader with standard PC/SC interface. Support 2 SAM slots. Based on ARM7 processor.



5.2.3 Communication port

S: RS232C interface, power supply from USB

R: RS485 interface, power supply by wire connection

U: USB interface

E: Ethernet interface, power supply by AC adaptor

5.2.4 Supported card type

A: ISO14443A, MIFARE classic and ISO7816

C: ISO14443A, ISO14443B, MIFARE classic and ISO7816

G: ISO15693 and ISO7816

H: ISO14443A, ISO14443B, ISO15693, MIFARE classic and ISO7816

5.2.5 Color of enclosure

W: white (if blank, default white)

B: black

5.2.6 ODM code

This part is for ODM customer only. It is 3 digital codes like 001, 002...

5.3 Model available

The models below are available for supply:

- MR7622UC
- MR7622UG
- MR7622UH

6 USB Driver installation

The driver installation is simple. Just plug the USB header into the PC, the OS will automatic install the drivers.



7 About PC Software

The PC software is TransConfig. It is use for load configuration file to the reader. Please download TransConfig from our website: http://www.jinmuyu.com, or contact us with jinmuyu@vip.sina.com.